



## Firmware upgrade

Model: iKeyboard 3/4/5/6/8  
 Release date: 22<sup>nd</sup> March, 2018  
 Version: V3.05  
 Who need to upgrade: All users  
 Upgrade fix or added features: Major “C” switching method  
 Hold a key-switch and press the “Transpose” button, the original  
 Major “C” key-switch will be shifted to the note that the key-switch  
 pressed previously

**Note: If your device’s serial number within the below range, please download firmware V2.xx**

iKeyboard 3	iKeyboard 4	iKeyboard 5	iKeyboard 6
2013C3433 - 2013C33631	2013C3728 - 2013C3926	2013D0462 - 2013D0659	2013D0660 - 2013D0857
1CJ1436 - 1CJ1585	1CJ1240 - 1CJ1433	2013D2431	1CI1898 - 1CI2097
1CK1318 - 1CK1347	1CJ0935 - 1CJ0940	1CJ0935 - 1CJ0940	1CK1218 - 1CK1317
1DK5534 - 1DK5733	1DI1063 - 1DI1162	1CK1348 - 1CK1547	1DL0501 - 1DL0700
1EG00001 - 1EG00200	1DI2753 - 1DI2852	1DI0963 - 1DI1062	1EB0201 - 1EB0400
	1EG00201 - 1EG00500	1DI2653 - 1DI2752	1EG00801 - 1EG01098
		1EB0001 - 1EB0200	1EI05256 - 1EI05755
		1EG00501 - 1EG00800	
		1EI04556 - 1EI05155	

## Update footprint

Version	Release date	Feature added or bug fix
V3.04	6 <sup>th</sup> July, 2016	1. Enable LED to display Pan value 2. Bitwig mode added 3. Flip function added (Press I< and <<8 buttons simultaneously)

Remark: