

Platform M+ / Platform X+ / Platform D2

ENGLISH Platform M+ / Platform X+ / Platform D2 Quick Start Guide
FRANÇAIS Platform M+ / Platform X+ / Platform D2 Guide de démarrage rapide
DEUTSCHE Schnellstartanleitung der Platform M+ / Platform X+ / Platform D2
ITALIANO Platform M+ / Platform X+ / Platform D2 Manuale di utilizzo rapido
ESPAÑOL Guía de inicio rápido de Platform M+ / Platform X+ / Platform D2
日本語 Platform M+ / Platform X+ / Platform D2 クイックスタートガイド



Platform M+ / Platform X+

Unpack Auspacken Desembalaje
Déballer Disimballare il contenuto パッケージを開く



- Platform M+ / Platform X+
- LED① = MCP (Nuendo/Cubase Samplitude Ableton Live Reaper Studio One Reason Bitwig Sonar Audition FL Studio Digital Performer)
 - LED② = Logic Pro
 - LED③ = HUI (Pro Tools)
 - LED④ = User define

Platform D2


Unpack Auspacken Desembalaje
Déballer Disimballare il contenuto パッケージを開く








Platform M+ / Platform X+ / Platform D2






For Mackie Control / HUI







Samplitude






Studio One










Logic Pro








Reaper









Pro Tools



Reason



Nuendo



Bitwig

