









## Setup up for your iKeyboard 3S controller section





# Setup for your iKeyboard 3S Keyswitch instrument input section





Search

User Locations

Search



ALL Instrument Patches

9

Name

Modified


+  Bass	2007/9/4 10:15
+  Bells and Mallets	2007/9/4 10:15
+  Brass	2007/9/4 10:15
+  Drums and Percussion	2007/9/4 10:15
+  Guitar and Plucked	2007/9/4 10:15
+  Organ	2007/9/4 10:15
+  Pads	2007/9/4 10:15
+  Performance Patches	2007/9/4 10:15
-  Piano and Keyboard	2007/9/4 10:15
+  Acoustic Piano	
-  Electric Piano	11
Bright EPiano.zyp	2007/9/4 10:15
CCRMA E Piano.zyp	2007/9/4 10:15
CLAVINETD6.smp	2007/9/4 10:15
Electric Koto.xwv	2007/9/4 10:15
Elpiano.zyp	12
ElPiano2.zyp	2007/9/4 10:15
EPianoesce.zyp	2007/9/4 10:15
Film Piano.xwv	2007/9/4 10:15

## Details

**Patch Type:** SubTractor

## Audition

Play

 Auto

Select



Select

13

OK

Cancel