

iCON
PRO AUDIO



AIRMON-4X

Wireless Monitoring System



www.iconproaudio.com

Cautions

 <p>Dangerous</p>	<ul style="list-style-type: none">Do not use the headphone while driving, cycling or walking on the road, this may cause traffic accident.	 <p>Forbidden</p>
--	--	--

 <p>Dangerous</p>	<ul style="list-style-type: none">Do not unplug the headphone's jack by pulling its cable.	 <p>Forbidden</p>
	<ul style="list-style-type: none">Do not attempt to disassemble or modify the internal elements of the headphones.	 <p>Forbidden</p>
	<ul style="list-style-type: none">Keep the headphones away from the children to avoid any accident happen.	

Pairing method of the receiver and the transmitter



Note: The Airmon 4X receiver must be used in conjunction with the Airmon 4 transmitter.

- Long-press the power buttons of both the receiver and transmitter to turn them on. The indicator lights will flash slowly.
- Press and hold the pairing button of the receiver and short-press the power button of the transmitter. The indicator lights will flash rapidly to enter the pairing state.

The frequency pairing is successful when the indicator lights of both the receiver and transmitter stay constantly on.

- Connect the transmitter to the sound card or other 3.5mm headphone jack, and plug a 3.5mm headphone into the Airmon 4X (receiver) to achieve wireless monitoring.

1. Long-press the power buttons of the receiver and transmitter for 3 seconds to turn on the devices, and the power indicator lights will flash slowly.



2. Long-press the pairing button of the receiver and short-press the power button of the transmitter. The receiver and transmitter will automatically enter the pairing state, and the power indicator lights will flash rapidly. When the devices are successfully paired, the pairing indicator light of the receiver and the power indicator light of the transmitter will stop flashing and remain constantly on.



When the battery is low, the battery indicator light of the Airmon 4X receiver stays constantly red.

Product Specifications

Wireless Frequency: 5.8GHz

Frequency Response: 20Hz-20kHz

Sampling Rate: 16Bit/48kHz

SNR: 97dB

Wireless Monitoring Distance: $\leq 10\text{m}$

Dynamic Range: 98dB

3.5mm Interface Output Power: 70mW (32Ω)

Receiver Battery Capacity: 600mAh

Services

If your Airon 4X needs servicing, follow these instructions.

Check our online Help Center at <http://support.iconproaudio.com/hc/en-us> information, knowledge, and downloads such as:

1. FAQ
2. Download
3. Learn More
4. Forum

Very often you will find solutions on these pages. If you don't find a solution, create a support ticket at our online Help Center at the link below, and our technical support team will assist you as soon as we can.

Navigate to <http://support.iconproaudio.com/hc/en-us> and then sign in to submit a ticket.

As soon as you have submitted an inquiry ticket, our support team will assist you to resolve the problem with your ICON ProAudio device as soon as possible.

To send defective products for service:

1. Ensure the problem is not related to operation error or external system devices.
2. Keep this owner's manual. We don't need it to repair the unit.
3. Pack the unit in its original packaging including end card and box. This is very important. If you have lost the packaging, please make sure you have packed the unit properly. ICON is not responsible for any damage that occurs due to non-factory packing.
4. Ship to the ICON tech support center or the local return authorization. See our service centers and distributor service points at the link below:

If you are located in US

Send the product to:

North America

Mixware, LLC – U.S. Distributor
11070 Fleetwood Street – Unit F.
Sun Valley, CA 91352; USA

Tel.: (818) 578 4030

Contact: www.mixware.net/help

If you are located in Europe

Send the product to:

Sound Service

GmbHEuropean

HeadquarterMoriz-Seeler-Straße
3D-12489 Berlin

Telephone: +49 (0)30 707 130-0

Fax: +49 (0)30 707 130-189

E-Mail: info@sound-service.eu

If you are located in Hong Kong

Send the product to:

ASIA OFFICE:

Unit F, 15/F., Fu Cheung Centre,
No. 5-7 Wong Chuk Yueng
Street, Fotan,

Sha Tin, N.T., Hong Kong.

Tel: (852) 2398 2286

Fax: (852) 2789 3947

Email: info.asia@icon-global.com

5. For additional update information please visit our website at:

www.iconproaudio.com

iCON
P r o A u d i o



天猫官方旗舰店



天猫店*iconproaudio*旗舰店

抖音号



抖音*ICON*工厂

哔哩哔哩



B站*ICONProAudio*

微信公众号



微信号*ICON-PRO*

官方微博



4006311312.114.qq.com

中国地区用户

Twitter



www.twitter.com/iconproaudio

Instagram



www.instagram.com/iconproaudio

Facebook



www.facebook.com/iconproaudio

Youtube



www.youtube.com/iconproaudio

Website



www.iconproaudio.com

Support



support.iconproaudio.com

Dashboard



iconproaudio.com/dashboard/

www.iconproaudio.com