iConPad functional firmware upload procedure